

KICKITTM

BILLET ALUMINUM KICKSTANDS

Thank you for your purchase! We are confident that you will be pleased with the quality of our product.

Instructions: (PMB-01-3010)

NOTE: We recommend using a thread-locking agent on all bolt threads.

- 1) Remove the bolt attaching the stock kickstand and slide the kickstand off the frame.
- 2) Detach and remove the kickstand spring and remove the shim that sits behind the stock kickstand.
- 3) Remove the cotter pin and washer from the footpeg. Slide the footpeg pin up slightly, but do not remove (see picture below).
- 4) Slide the Pro Moto Billet kickstand onto the frame and secure with the stock kickstand bolt.
- 5) Slide footpeg pin back into place and re-install washer and new cotter pin.
- 6) Periodically check all mounting bolts for tightness.

To prevent damage:

- Clean and lubricate the kickstand pivot area after each ride! We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.
- Carefully position kickstand up and down.
- Do not Start/sit on bike with the kickstand down.



Parts List:
1-Kickstand
1-Cotter Pin

Check out our Spark Arrestor Endcaps, Billet Cargo Racks, Shark Fins and other billet accessories at...

PROMOTO
BILLET.COM