



Thank you for your purchase, we are confident that you will be pleased with the quality of our product.

Instructions: 10-14 Suzuki RMZ 250/450

PMB-01-4008

To install your new kickstand:

1. Remove the left foot peg and bracket.
2. Install the kickstand under the left foot peg bracket using the stock bolts. We recommend using a removable thread-locking agent on the bolts. Make sure you tighten the foot peg bracket bolts to the correct torque per your owner's manual.
3. Re-install the foot peg.
4. Periodically check the foot peg mounting bolts, and kickstand pivot bolt for tightness.

Maintenance: Clean and lubricate the kickstand pivot area after each ride. We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.

CAUTION: We do not recommend starting the bike with the kickstand down, as this may cause damage to the kickstand.

Manufactured and Distributed by:

**Pro Moto Billet
11461 Lone Star RD
Nampa ID 83651
208-466-4762**

Check out our Spark Arrestor Endcaps, Billet Cargo Racks, Shark Fins and other billet accessories at...

